

e53 X5-series Installation Instructions

Tools required – None!

Step One: Open hood, look down at the headlight. You will see a black plastic cover, at an angle on the back of the headlight (on the drivers side, the space may be more cramped). Open this cover.

Step Two: Unplug the OEM wiring plug from the back of the OEM Angel Eye reflector unit (the OEM Angel Eye unit is bronze in color, and the plug is black with a grey and brown wire).

Step Three: Insert the Angel iBright unit. CustomAngelEyes kept the same OEM seal to ensure the fitment back into the housing. The trick is there are 3 notches on the light housing, 2 are angled and one is not. Make sure it is inserted properly and securely, you may need to apply some pressure to compress the unit while twisting (it is designed to sit perfectly flush against the fiber-optic cable). You can either plug in the new wiring harness before or after the re-insertion of the new Light.

Step Four: Replace black cover. And repeat for other headlight.

Step Five: Enjoy, and send us/post plenty of pictures!

www.AngeliBright.com

