

TPH installation guide



- 1) Begin by removing the Tow Hook protector cap with a flat head screwdriver.
- 2) Install the main bolt into the Tow Hook screw hole. Tighten securely. Loctite may need to be used to tighten securely.



- 3) Use the correct screw-in headless extension bar by selecting from the two length provided. Test it with the plate holder frame, nut, lock washer and as many washers as needed to install the holder without touching the bumper. Do a try test first before using lock tight incase the screw is too long or too short.



4) Dress the screw with Loctite and use a large flat head blade to screw in.



5) Use the correct number of washer to extend the plate holder away from the bumper. You can use a bit of Loctite between each washer to prevent the possibility of rotation but this is not necessary.



6) Place the license plate holder over the screw.



7) Affix the lock washer and then nut. Tighten securely making sure the plate holder is horizontal with the ground.



8) Align the plate holding side brackets to the main plate bracket.



9) Use the 4 provided screws and nuts to mount your plate to the holder. After your first time driving make sure none of the assembly has rotated or loosened.

It is the customer's responsibility to make sure everything is mounted securely. Failure to do so may result in a lost plate or a scratched bumper due to rotation of plate.